


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS


Illus No.		DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus No		DESCRIPTION
1	8304535 8304531 8304549 8304550	Literature Parts Installation Instructions Use & Care Guide Tech Sheet English French Easy Set Guide Safer Cooking Tips English	14 15 16 17 18 19 21	8304627 8304493 4452158 4449040 3400893 4451478 8303675BL 8303676BL 8303692 4449743	Frame, Front Gasket, Door Tube, Vent Screw Screw Support, Insulation Mounting Rail,Side Right Left Latch, Mortorized	37 38 39 40 41 42 43 44 45 46	4449154 8304598 W10077010 W10111418 W10076760 2314271 W10140567 W10076910 9761146	Screw Enclosure Gasket, Enclosure Valve, Solenoid Sensor, Conductivity Slip Fit Valve, Check Tubing
2 3 4	4455606 4455605		25	4455641	Rail (6) Side, Chassis Back, Chassis Liner, Oven (Not serviceable)	47 48 49		Switch, Pressure Hose (includes clamp)
5 6 7	8303829 8304618	Exhaust, Vent Slope Divider, Vent Top Chassis	28 29 30	8304452 4455636 4449748	Thermal Fuse Sensor			/ING PARTS USTRATED
9 10 11 12 13	4449809 3196176 4452163 4448972	Screw Screw Lens, Light Oven Light, Assembly Bulb, Light	31 32 33 34 35	8303516 W10139288 8303517 8303705SS 9758597	Base, Chassis Retainer, Gasket Cover, Back Trim, Bottom Vent Orifice, Boiler Slip Fit Cover, Boiler Orifice	INS		Insulation, Wrap Insulation, Back

CONTROL PANEL PARTS




llus No.	. Part No.	DESCRIPTION
1	8303716SS	Panel, Control
2	8303687	Support Appliance
		Manager
3	8303797	Bracket, Glass
		Touch
4	W10016010	Control Panel,
		Glass Touch
5	W10138654	User Interface
6	8303719	Backer, Control
7	8303887	Bracket, Enclosure
8	4449154	Screw
9	3400832	Screw
10	W10140626	Appliance Manager
11	8304441	Resistor, Drop
12	W10134765	Vapor, Stop
13	3400805	Screw
14	9760749	Bumper
15	4449809	Screw

OVEN DOOR PARTS




Illus. Pa	=	Illus. <u>No.</u>	Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION
2 8303 3 3196 4 830458 5 8304	BL Door Liner 89 Hinge, Door (2) 83 Screw BL Vent, Door Top Bracket, Door 77 Right 78 Left	10	8303731 4449743 8303745BL 8304523 8304360BL	Frame, Door Side	13 15 16 17	8304603SS 8304522	Bumper, Glass Cover, Hinge Right Left

INTERNAL OVEN PARTS



TOP VENTING PARTS



Illus. No.	Part No.	DESCRIPTION
	0004040	O T
1		Cover, Top
2	8304643	Duct, Air Outlet
3	4449809	Screw
4	8303972	Blower
5	9760588	Transformer,
		Lights
6	8285593	Connector, Cover
7	9762885	Transformer,
		Control
9	4449868	Block, Terminal
10	3400080	Screw
11	8303684	Vent, Control
		Panel
12		Side, Control Top
	8303518	
	8304255	
13		Back, Control
14	4450118	
15	8304641	
10	0304041	Strip, Blower (2)

OPTIONAL PARTS

Illus. Part No. No.	DESCRIPTION	Illus. Part No. No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH-UP (1/2oz.)		SPLICING WIF	RES25FT.	WIRI	NG HAI	RNESS PARTS
26186 7203 PAINT, SP 35093 26190 83086 ADHESIVE	0 White 0 Citrine White 4 Black	24282 24282 24282 24283 24282 24282 24282 24282 24283 24282 24283	3 Wire (12 Ga. 150 c Black) 0 Wire (14 Ga. 150 c Black) 1 Wire (14 Ga. 150 c Blue) 2 Wire (14 Ga. 150 c Brown) 0 Wire (14 Ga. 200 c Brown) 3 Wire (14 Ga. 150 c Green) 4 Wire (14 Ga. 150 c Orange) 9 Wire (12 Ga. 150 c Red) 5 Wire (14 Ga. 200 c Red) 6 Wire (14 Ga. 200 c Red) 7 Wire (14 Ga. 150 c Vellow) 2 Wire (14 Ga. 200 c Yellow) 2 Wire (14 Ga. 200 c Yellow)	Misc W W	10136382 8304318 8304611 4450800 4454842 ellaneo 4448950 2308388 10111330 10051680 10110634 10049700	Harness, Latch Harness, Main Communication, Harness Conduit, Single Screw, Ground Tie, Cable US Screw, Install (4) Stainless Cleaner Filter, Cartridge Reducer, Stem Tube, Water Supply Filter Assembly Elbow, Plug In